

**IMPORTANT**

THIS BOOKLET CONTAINS EMISSION CONTROL SYSTEMS MAINTENANCE AND WARRANTY INFORMATION THAT IS PROVIDED BY DETROIT IN COMPLIANCE WITH THE FEDERAL CLEAN AIR ACT.

IT ALSO PROVIDES THE DATE OF VEHICLE DELIVERY AND MILEAGE AT TIME OF DELIVERY. PLEASE KEEP THIS BOOKLET WITH THE VEHICLE AND MAKE IT AVAILABLE TO ANY AUTHORIZED DETROIT SERVICE LOCATION IF WARRANTY WORK IS REQUIRED.

**NOTICE TO PURCHASERS OF DD  
PLATFORM ENGINES INSTALLED IN  
VEHICLES SOLD OUTSIDE THE US.**

Vehicles sold outside the U.S. are equipped with odometers reading in kilometers. To convert warranty and maintenance mileage limitations to kilometers, refer to the table below.

**WARRANTY AND MAINTENANCE MILEAGE/  
KILOMETER CONVERSION TABLE**

Miles	Kilometers
4,000	6,400
6,000	9,600
10,000	16,000
12,500	20,000
20,000	32,000
25,000	40,000
30,000	48,000

Miles	Kilometers
40,000	64,000
50,000	80,000
60,000	96,000
70,000	112,000
80,000	128,000
90,000	144,000
100,000	160,000

Owner's Name \_\_\_\_\_

Engine Serial No. \_\_\_\_\_

Engine Model No. \_\_\_\_\_

Date of Delivery \_\_\_\_\_

Miles/Km at Delivery Date \_\_\_\_\_

## CONTENTS

CONTENTS.....	3
INTRODUCTION.....	4
LIMITED WARRANTY ON NEW DETROIT DD8, GHG17, MEDIUM DUTY ENGINES USED IN ECONIC VEHICLE APPLICATIONS .....	5
EMSSION CONTROL SYSTEMS INFORMATION .....	8
CALIFORNIA EMISSION CONTROL SYSTEMS WARRANTY STATEMENT.....	10
DETROIT'S EMSSION CONTROL SYSTEM WARRANTY COVERED COMPONENTS.....	11
THINGS YOU SHOULD KNOW ABOUT THE EMISSION CONTROL SYSTEMS' WARRANTY .....	13
U.S. CLEAN AIR ACT .....	15
EXPLANATION OF OWNER'S MAINTENANCE SERVICES .....	16
OWNER'S EMISSION CONTROL MAINTENANCE SERVICE CHARTS.....	18
Severe Service Maintenance Intervals DD8, GHG17 .....	18
LUBRICATING OIL ANALYSIS – WARNING VALULES.....	20
POLICY ON OWNER SERVICE .....	22
FUEL ADDITIVES .....	23
CUSTOMER ASSISTANCE PROCEDURE.....	26
MAINTENANCE RECORD LOG.....	27

## INTRODUCTION

### ***An Important message to Detroit Diesel Product Owners...***

This booklet contains emission control systems maintenance and warranty information that is provided by Detroit in compliance with the U.S. (Federal) Environmental Protection Agency, Emission Regulations under the Canada Motor Vehicle Safety Act in Canada, and the California Air Resources Board. An emission label is attached to the cylinder head cover, as required by law.

Also contained in this booklet is warranty information applicable to the product you have purchased.

## **LIMITED WARRANTY ON NEW DETROIT DD8, GHG17, MEDIUM DUTY ENGINES USED IN ECONIC VEHICLE APPLICATIONS**

### **TERMS OF COVERAGE:**

#### **Uses**

This warranty applies to the first retail purchaser and subsequent owners during the WARRANTY PERIOD of new Detroit Diesel GHG17, DD8 Engines (referred to as Engine) manufactured by Detroit Diesel and/or supplied by Detroit Diesel or Detroit Diesel of Canada Limited (which are collectively referred to as Detroit) for use in on-highway vehicle applications operated outside the United States and Canada.

#### **Defects**

This warranty covers Engine REPAIRS to correct any malfunction occurring during the WARRANTY PERIOD resulting from defects in material or workmanship.

#### **Repairs**

To obtain warranty repairs, you must request the needed repairs within the WARRANTY PERIOD from a Detroit Authorized Service Outlet. Only new genuine parts or remanufactured parts or components supplied or approved by Detroit will be used. Detroit may, at its discretion, replace rather than repair components. A reasonable time must be allowed to perform the warranty repair after taking the engine to the authorized service outlet. The owner is responsible for the percentage of repair costs shown in the warranty period chart. Repairs will be performed during normal business hours.

#### **Warranty Period**

The WARRANTY PERIOD begins on the date the engine is delivered to the first retail purchaser or put in use prior to sale at retail, whichever date occurs first, and ends at the time or mileage/kilometer limits shown in the WARRANTY PERIOD chart.

#### **Like Replacement Engine**

Engine(s) supplied by Detroit as a replacement for an engine still under warranty will assume the identity of the engine being replaced and be entitled to the remaining warranty coverage.

#### **Service Supplies**

The cost of service supplies such as coolant, oil and filters which are not reusable due to needed warranty repairs is covered by this warranty.

#### **Engine Removal and Reinstallation**

Reasonable labor costs for Engine removal and reinstallation, when necessary to make a warranty repair, are covered by this warranty.

**Towing**

During the base warranty period reasonable towing costs to the nearest authorized service outlet are covered by the warranty when due to a warrantable failure and the engine is either inoperable, cannot be safely operated or continued operation would cause further damage to the Product.

<b>WARRANTY PERIOD Econic Vehicle Applications</b>				
<b>Item</b>	<b>Warranty Limitations (Whichever Occurs First)</b>		<b>Repair Charge To Be Paid By Owner</b>	
	<b>MONTHS</b>	<b>MILES/km</b>	<b>PARTS</b>	<b>LABOR</b>
Engine	0-36	250,000 mi 402,000 km	No Charge	No Charge
Emissions	0-60	100,00 mi 160,000 km 250,000 mi 402,000 km from 0-36 months	No Charge	No Charge
Accessories	0-24	0-100,000 mi 0-160,000 km	No Charge	No Charge

Emissions Warranty: Refer to the EMISSION CONTROL SYSTEM INFORMATION section in the Warranty Booklet for included components.

## **THIS WARRANTY DOES NOT COVER**

### **Repairs Due to Accidents, Misuse, Storage Damage, Negligence or Certain Modifications**

Repairs due to an accident, misuse, misapplication, storage damage, negligence or modification exceeding Detroit specifications are not covered by this warranty.

### **Maintenance**

Detroit is not responsible for the cost of maintenance or repairs due to lack of performance of required maintenance services as recommended by Detroit, or the failure to use fuel, oil, lubricants and coolant meeting Detroit recommended specifications. Performance of the required maintenance and use of proper fuel, oil, lubricants and coolant are the responsibility of the owner. Refer to the Engine Operator's Guide for details.

### **Incidental or Consequential Damages**

Detroit is not responsible for incidental or consequential costs or expenses which the owner may incur as a result of a malfunction or failure covered by this warranty, such as communication expenses, meals, lodging, loss of use of the engine or vehicle ("downtime"), loss of time, inconvenience, cargo loss or damage, and other similar costs and expenses.

### **Other Limitations**

The performance of REPAIRS is the exclusive Owner's remedy under this warranty. Detroit does not authorize any person to assume or create for it any other obligation or liability in connection with the engine or the accessories.

THIS WARRANTY AND THE EMISSION CONTROL SYSTEMS' WARRANTY ARE THE ONLY WARRANTIES APPLICABLE TO THE ENGINE AS USED IN ON-HIGHWAY VEHICLE APPLICATIONS. DETROIT MAKES NO OTHER WARRANTIES EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. DETROIT SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES AS DESCRIBED ABOVE.

Some states do not allow the limitation of how long this warranty may last or the limitation or exclusion of incidental or consequential damages, so the above may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state.

## EMSSION CONTROL SYSTEMS INFORMATION

### FEDERAL EMISSION CONTROL SYSTEMS WARRANTY COVERING DETROIT ENGINES

Detroit warrants to the owners of Detroit DD8, GHG17 Engines built with standard exhaust emissions components, that the engine (1) was designed, built and equipped so as to conform, at the time of sale, with applicable regulations of the U.S. (Federal) Environmental Protection Agency, Emission Regulations under the Canada Motor Vehicle Safety Act in Canada, and the California Air Resources Board and (2) is free from defects in material and workmanship which cause the engine to fail to conform with those regulations for a period of 100,000 miles or five years of engine operation, whichever occurs first, or the new product warranty, if the product warranty is longer.

The warranty period shall begin on the date the vehicle is delivered to the first retail purchaser or, if the vehicle is first placed in service as a demonstrator prior to sale at retail, on the date the vehicle is first placed in such service. Emission related defects in the genuine Detroit components listed below, including reasonable related diagnostic costs, are covered by this warranty.

### WHAT IS COVERED

These components are covered by the above warranty. Some scheduled maintenance is required (refer to the Owner's Emission Control Maintenance Service Chart).

**The Aftertreatment System:** The Aftertreatment System (ATS) will be covered under the base warranty period of the engine.

- Turbocharger
- Motor Control Module (MCM)
- EGR Cooler
- Camshaft Position Sensor
- Crankshaft Position Sensor
- Oil Temperature Sensor
- Intake Manifold Pressure Sensor
- Intake Manifold Temperature Sensor
- Fuel Temperature Sensor
- Coolant Outlet Temperature Sensor
- Intake Throttle Valve and Adaptor
- Delta P Sensor
- Fuel Injector
- EGR Valve and Actuator
- Charge Air Cooler Outlet Sensor
- High Pressure Fuel Pump
- Turbo Speed Sensor



## **The Aftertreatment System:**

- Intake Throttle Valve
  - Doser Block Assembly
  - Fuel Doser Valve
  - Oxidation Catalyst
  - Particulate Filter
  - DOC Inlet Temperature Sensor
  - DOC Outlet Temperature Sensor
  - DPF Inlet Pressure Sensor
  - DPF Outlet Pressure Sensor
  - DPF Outlet Temperature Sensor
  - ATD Wiring Harness
  - Aftertreatment Control Module (ACM)
  - \* Exhaust Fluid Pump
  - \* Fuel Rail Pressure Sensor
  - \* Fuel Pressure sensor (Low)
  - \* Lo Dosing Unit
  - DEF Temperature Sensor NOX Sensors
  - SCR Catalyst
- \* *DEF (Exhaust Fluid)*

## **WHAT IS NOT COVERED**

These components are covered by the above warranty. Some scheduled maintenance is required (refer to the Owner's Emission Control Maintenance Service Chart).

- Conditions resulting from tampering, misuse, improper adjustments, alteration, accident, failure to use recommended fuel or non-performance of required maintenance services;
- The replacement of non-warranted maintenance parts;
- Consequential damages such as loss of time, inconvenience, economic loss, loss of use of the engine or vehicle;
- Any engine in a vehicle on which odometer mileage has been changed so that the mileage cannot be readily determined;
- Periodic maintenance of the Particulate Filter (cleaning)

**DETROIT DIESEL CORPORATION DOES NOT AUTHORIZE ANY PERSON TO CREATE FOR IT ANY OTHER OBLIGATION OR LIABILITY IN CONNECTION WITH THESE SYSTEMS. THIS WARRANTY IS IN ADDITION TO THE NEW DETROIT ENGINE WARRANTY FOR ON-HIGHWAY VEHICLE APPLICATIONS.**

## **CALIFORNIA EMISSION CONTROL SYSTEMS WARRANTY STATEMENT**

### **YOUR WARRANTY RIGHTS AND OBLIGATIONS**

The California Air Resources Board and Detroit are pleased to explain the emission control system warranty on your DD8, GHG17 engine. In California, new motor vehicles must be designed, built and equipped to meet the State's stringent anti-smog standards. Detroit must warrant the emission control system on your engine for the periods of time listed below provided there has been no abuse, neglect or improper maintenance of your engine.

Your emission control system may include parts such as the fuel injection system, the turbocharger and engine computer. Also included may be hoses, belts, connectors and other emission-related assemblies.

Where a warrantable condition exists, Detroit will repair your engine at no cost to you including diagnosis, parts and labor.

### **MANUFACTURER'S WARRANTY COVERAGE:**

For a period of use of five (5) years or 100,000 miles or 3,000 hrs of operation, whichever occurs first:

If an emission-related part on your engine is defective, the part will be repaired or replaced by Detroit. This is your emission control system DEFECTS WARRANTY.

### **OWNER'S WARRANTY RESPONSIBILITIES:**

These components are covered by the above warranty. Some scheduled maintenance is required (refer to the Owner's Emission Control Maintenance Service Chart).

- As the engine owner, you are responsible for performing the required maintenance listed in your owner's manual. Detroit recommends that you retain all receipts covering maintenance on your engine, but Detroit cannot deny warranty solely for the lack of receipts or for your failure to ensure the performance of all scheduled maintenance.
- You are responsible for presenting your engine to an Detroit Authorized Service Outlet as soon as a problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.
- As the engine owner, you should also be aware that Detroit may deny you warranty coverage if your engine or a part has failed due to abuse, neglect, improper maintenance or unauthorized modifications.

If you have any questions regarding your warranty rights and responsibilities, you should contact Manager Service Operations at (313) 592-5000 or the California Air Resources Board P.O. Box 8001, El Monte, CA 91731-2990.

## DETROIT'S EMISSION CONTROL SYSTEM WARRANTY COVERED COMPONENTS

### WHAT IS COVERED

These components are covered by the above warranty. Some scheduled maintenance is required (refer to the Owner's Emission Control Maintenance Service Chart).

**The Aftertreatment System:** The Aftertreatment System (ATS) will be covered under the base warranty period of the engine.

- Turbocharger
- Motor Control Module (MCM)
- EGR Cooler
- Camshaft Position Sensor
- Crankshaft Position Sensor
- Oil Temperature Sensor
- Intake Manifold Pressure Sensor
- Intake Manifold Temperature Sensor
- Fuel Temperature Sensor
- Coolant Outlet Temperature Sensor
- Intake Throttle Valve and Adaptor
- Delta P Sensor
- Fuel Injector
- EGR Valve and Actuator
- Charge Air Cooler Outlet Sensor
- High Pressure Fuel Pump
- Turbo Speed Sensor

Emergency Repair Contact

See Nearest Authorized Dealer/Distributor or call 1-800-445-1980

## **The Aftertreatment System:**

- Intake Throttle Valve
  - Doser Block Assembly
  - Fuel Doser Valve
  - Oxidation Catalyst
  - Particulate Filter
  - DOC Inlet Temperature Sensor
  - DOC Outlet Temperature Sensor
  - DPF Inlet Pressure Sensor
  - DPF Outlet Pressure Sensor
  - DPF Outlet Temperature Sensor
  - ATD Wiring Harness
  - Aftertreatment Control Module (ACM)
  - \* Exhaust Fluid Pump
  - \* Fuel Rail Pressure Sensor
  - \* Fuel Pressure sensor (Low)
  - \* Lo Dosing Unit
  - DEF Temperature Sensor NOX Sensors
  - SCR Catalyst
- \* *DEF (Exhaust Fluid)*

## **WHAT IS NOT COVERED**

- Conditions resulting from tampering, misuse, improper adjustments, alteration, accident, failure to use recommended fuel or non-performance of required maintenance services;
- The replacement of non-warranted maintenance parts;
- Consequential damages such as loss of time, inconvenience, economic loss, loss of use of the engine or vehicle;
- Any engine in a vehicle on which odometer mileage has been changed so that the mileage cannot be readily determined;
- Periodic maintenance of the Particulate Filter (cleaning)

**DETROIT DIESEL CORPORATION DOES NOT AUTHORIZE ANY PERSON TO CREATE FOR IT ANY OTHER OBLIGATION OR LIABILITY IN CONNECTION WITH THESE SYSTEMS. THIS WARRANTY IS IN ADDITION TO THE NEW DETROIT ENGINE WARRANTY FOR ON-HIGHWAY VEHICLE APPLICATIONS.**

## **THINGS YOU SHOULD KNOW ABOUT THE EMISSION CONTROL SYSTEMS' WARRANTY**

### **REPLACEMENT PARTS**

The emission control systems of your new Detroit Engine were designed, built and tested using Genuine Detroit Parts\* and the engine is certified as being in conformity with applicable regulations of the U.S. (Federal) Environmental Protection Agency, Emission Regulations under the Canada Motor Vehicle Safety Act in Canada, and the California Air Resources Board. Accordingly, it is recommended that any replacement parts used for maintenance or for the repair of emission control systems be new, Genuine Detroit Parts.

THE WARRANTY OBLIGATIONS ARE NOT DEPENDENT UPON THE USE OF ANY PARTICULAR BRAND OF REPLACEMENT PARTS. THE OWNER MAY ELECT TO USE NON-GENUINE DETROIT PARTS FOR REPLACEMENT PURPOSES. USE OF REPLACEMENT PARTS WHICH ARE NOT OF EQUIVALENT QUALITY MAY IMPAIR THE EFFECTIVENESS OF EMISSION CONTROL SYSTEMS.

If other than Genuine Detroit Parts are used for maintenance replacements or for the repair of components affecting emission controls, the owner should assure himself/herself that such parts are warranted by their manufacturer to be equivalent to Genuine Detroit Parts in performance and durability.

### **MAINTENANCE AND REPAIRS**

MAINTENANCE AND REPAIRS CAN BE PERFORMED BY ANY QUALIFIED SERVICE OUTLET; HOWEVER, WARRANTY REPAIRS MUST BE PERFORMED BY AN AUTHORIZED DETROIT SERVICE OUTLET. Receipts covering the performance of regular maintenance should be retained in the event questions arise concerning maintenance. These receipts should be transferred to each subsequent owner of this vehicle. Detroit reserves the right to deny warranty coverage if the required maintenance has not been performed. However, this decision would not be based solely on the absence of maintenance records.

Repairs covered by this warranty will be made at no charge by a Detroit Authorized Service Outlet. If in an emergency situation it is necessary to have repairs performed by other than a Detroit Authorized Service Outlet because an authorized outlet is not reasonably available, repairs may be performed at any available service establishment or by the owner, using any equivalent replacement part. Detroit will reimburse the owner for expenses (including diagnosis), not to exceed Detroit's suggested retail price for all warranted parts replaced and labor charges based on Detroit's recommended time allowance for warranty repair and the geographically appropriate hourly labor rate. A part not being available within 30 days or a repair not being complete within 30 days constitutes an emergency. For reimbursement of the repairs that were performed, take the replaced parts and receipt to a Detroit Authorized Service Outlet for reimbursement consideration.

*\*"GENUINE DETROIT PARTS" when used in connection with Detroit Engines, means parts manufactured by or for Detroit, designed for use on Detroit Engines and distributed by Detroit . This definition includes remanufactured assemblies designated reliable and sold by authorized Detroit Distributors that may be used in performing warranty repairs.*

## U.S. CLEAN AIR ACT

The U.S. Clean Air Act requires the engine manufacturer to furnish, with each new engine to be installed in a motor vehicle, written instructions for proper maintenance and use of the vehicle or engine by the ultimate purchaser. The instructions shall correspond to regulations which the Administrator of the Environmental Protection Agency (EPA) shall promulgate. This booklet provides these instructions to owners in compliance with the law..

### **NORMAL ENGINE USE**

The owner's maintenance instructions contained in this booklet are based on the assumption that the engine will be used to power a motor vehicle which will be used as designed:

- To carry passengers and/or cargo within the weight limitations indicated on the Vehicle Identification Number (VIN) affixed to the vehicle;
- To operate within legal operating limits;
- To operate on a daily basis, as a general rule, for at least several miles, and;
- To operate on specified fuel and lubricating oils as covered in the Operator's Manual

Unusual operating conditions will require more frequent engine maintenance as specified in the Section "Explanation of Owner's Emission Control Maintenance Services."

## EXPLANATION OF OWNER'S MAINTENANCE SERVICES

1. **ENGINE LUBRICATING OIL:** Reference the Maintenance Service Charts in this booklet. Please reference our Detroit Diesel Customer Service Website for a list of approved engine lubricating oils.
2. **ENGINE LUBRICATING OIL FILTERS:** Reference the Maintenance Service Charts in this booklet.
3. **COOLANT:** Check the coolant level daily before starting the engine. Make sure coolant is up to the proper level. Add coolant as necessary. **DO NOT OVERFILL.** Check all cooling system lines and hoses for damage, leaks or loose connections. Tighten or replace as necessary. (Refer to Coolant Selections for Detroit Engines – DDC-SVC-BRO-0002). Please reference our Detroit Diesel Customer Service Website for a list of approved engine coolants.
4. **FUEL FILTERS:** Reference the Maintenance Service Charts in this booklet.
5. **DRY TYPE AIR CLEANER:** Under no operating condition should the intake restriction exceed 20 inches of water at full load and rated speed. A clogged air cleaner element will cause excessive intake restriction and a reduced air supply to the engine. For equivalent restriction limits for lower speed, refer to Detroit Corporation Engineering Bulletin No. 39, "Air Cleaner Systems for Detroit Engines." If the dry type air cleaner is equipped with an aspirator, check for aspirator damage or clogging. Clean and repair as necessary.
6. **TURBOCHARGER:** Inspect turbocharger mountings, air intake and exhaust ducts for leaks. Check the oil inlet and outlet lines and connections for leaks and for restrictions to oil flow. Check for unusual vibration or noises. If excessive, remove the unit from service and have cause corrected.

- *An emission control service.*



7. **AFTERTREATMENT DEVICE (ATD):** Under no operating conditions should the exhaust back pressure ahead of the particulate filter exceed 8.86" Hg (30kPa). At this level of back pressure, the Amber Warning Lamp (AWL) will be illuminated and a SPN 3720 Code will be set in the engine Motor Control Module (MCM). A clogged Particulate filter element will restrict air flow through the engine. Reference the Maintenance Service Charts in this booklet.
8. **PARTICULATE FILTER:** A "Check Engine Light" will illuminate when ash requires removal. Reference the Maintenance Service Charts in this booklet.
9. **DEF PUMP FILTER:** Reference the Maintenance Service Charts in this booklet for required replacement.
10. **VALVE LASH ADJUSTMENT:** Reference the Maintenance Service Charts in this booklet.

- *An emission control service.*

## OWNER'S EMISSION CONTROL MAINTENANCE SERVICE CHARTS

### **Severe Service Maintenance Intervals DD8, GHG17**

**Severe** service applies to vehicles that average below 6.5 miles per gallon or that operate under severe conditions. Examples of Severe Service are idle time over 40%, load factor over 55%, operation on extremely poor roads or under heavy dust accumulation; constant exposure to extreme hot, cold, salt-air, or other extreme climates; frequent short-distance travel; construction-site operation; farm operation or refuse application. Only one of these conditions is necessary to categorize an application as Severe service.

A list of approved Engine Lubricating Oils is available at [dtnaconnect.com](http://dtnaconnect.com) under Service Information > Lubricants, Fuels & Coolants > DFS Engine Oil Approval List.

Note: If your vehicle has the Maintenance System enabled, please follow the notifications communicated by that system. Not all items in the below table are monitored by the Maintenance System. If in doubt follow the below table to ensure proper engine care.

Key No.	DD8: Severe Service Maintenance Intervals GHG17 with ULSD Fuel GHG17 Using DFS 93K223(FA-4) or 93K222(CK-4) Approved Oils	
1	Lubricating Oil*	Replace every 45,000 miles (72,000 km) (1,500 hrs) (12 months) **
2	Lubricating Oil Filter*	Replace every 45,000 miles (72,000 km) (1,500 hrs) (12 months) **
3	Coolant – G40 SiOAT	Inspect every 90,000 miles (145,000 km) (1,500 hrs) (12 months) ** Replace every 300,000 miles (480,000 km) (3,000 hrs) (36 months)** For Coolant Service Information refer to ddc-svc-bro-0002.
4	Fuel Filters (frame and engine)	Replace every 45,000 miles (72,000 km) (1,500 hrs) (12 months) **
5	Belts	Inspect every 45,000 miles (72,000 km) (1,500 hrs) (12 months) ** Replace every 135,000 miles (217,000 km) (4,500 hrs) (36 months)**
	Air System	Inspect every 45,000 miles (72,000 km) (1,500 hrs) (12 months) **
	Air Cleaner	Refer to vehicle maintenance procedures
	Air Compressor	Inspect every 45,000 miles (72,000 km) (1,500 hrs) (12 months) **
6	Exhaust System*	Inspect every 45,000 miles (72,000 km) (1,500 hrs) (12 months) **
7	Aftertreatment Device	Inspect external hardware and connections every 6 months or at oil change intervals.**
8	Diesel Particulate Filter ***	A Check Engine Light will illuminate when ash requires removal. Normal DPF ash clean interval is every 150,000 miles (241,000 km) (5,000 hrs) ** Detroit DPF Cleaning Process (Liquid Cleaning)
9	DEF Pump Filter	Replace every 500,000 miles (805,000 km) (10,000 hrs) (3 years) **
10	Valve Lash Adjustment	Adjust every 90,000 miles (145,000 km) (3,000 hrs) (24 months) **
<p>*Check daily  **Whichever comes first.  ***Detroit highly recommends replacing the DPF with a Detroit genuine DPF to ensure maximum replacement life.  Currently, only Detroit™ Fuel Filter/Water Separator &amp; Davco 245 or Racor 6600 are the only frame-mounted filtration systems compatible for Detroit™ Engines.  Refer to "Routine Preventive Maintenance" for a description of all items.</p>		

The maximum oil drain and fuel filter replacement intervals for the DD8 listed above are based on engines operating with ULSD fuel (below 15ppm) with Detroit Fluids Specification (DFS) 93K223 or (DFS) 93K222 approved oils. The intervals listed above should be considered as maximum and should not be exceeded. For more details about oil quality, analysis and drain intervals, refer to Detroit publication Lubricating Oil, Fuel, and Filters, DDC-SVC-BRO-0001.

## LUBRICATING OIL ANALYSIS – WARNING VALULES

A fuel dilution exceeding 7% by volume indicates an immediate need for an oil change and corrective maintenance action. Fuel dilution can be confirmed by ASTM D3524 test procedure performed by oil suppliers or independent laboratories.

In addition to the above considerations, the oil drain interval for Detroit Engines has been exceeded if:

Single Sample Used-Oil Analysis Warning Limits			
Characteristics	ASTM or Other Methods	Conditions Measured	DD8
Viscosity at 100 °C, cSt, Min	D 445 DIN 51562	Engine & Oil	12.5 SAE 15W-40 / 9.3 SAE 10W-30/5W-30
Viscosity at 100 °C, cSt, Min	D 445 DIN 51562	Engine & Oil	21.9 SAE 15W-40 / 12.5 SAE 10W-30/5W-30
Soot, %*	TGA (E1131)	Engine Combustion	4.5†
Glycol, Max	D2982 DIN 51375	Engine	Negative
Water, Max	E203	Engine	0.3%
Fuel Dilution, Max	D3524	Engine	7%
Fe, Max ‡	D5185	Engine Wear	200 ppm
Al Max‡	D5185	Engine Wear	50 ppm
Si Max‡	D5185	Engine Wear	50 ppm
Cu, Max§	D5185	Engine Wear	50 ppm
Pb, Max‡	D5185	Engine Wear	10 ppm
Na, Max ‡	D5185	Engine Coolant Leak	100 ppm
K, Max §	D5185	Engine Coolant Leak	150 ppm
* Infrared spectroscopy (ASTM E 168/DIN 51452) may also be used, provided it is calibrated to be equivalent to the TGA method.			
† With Detroit Fluids Specification approved oils.			
‡ These are general limits. Wear metal limits must be determined for specific application and oil used.			
§ Results may exceed limits during engine break-in period; see Refer to section "Oil Analysis During Engine Break-In Period" for more information.			
NOTE: These limits are intended as guidance when a single oil sample is tested and are based on the normal oil drain intervals listed in Table "Maximum Oil Drain and Filter Change for DD8 using Detroit Fluids Specifications Approved Oils with ULSD Fuel." Actual limits are dependent on engine, application, drain interval and oil type.			

**Biodiesel General Recommendations and Guidelines**

Biodiesel blends up to 5% are compatible provided it meet the specifications listed in the Detroit Biodiesel Policy. [https://dtnacontent-](https://dtnacontent-dtna.prd.freightliner.com/content/dam/public/dtna-servicelit/ddc/pdfs/Lube_Oil_Coolant/Detroit_Bio_Fuel_Position_Statement.pdf)

[dtna.prd.freightliner.com/content/dam/public/dtna-servicelit/ddc/pdfs/Lube\\_Oil\\_Coolant/Detroit\\_Bio\\_Fuel\\_Position\\_Statement.pdf](https://dtnacontent-dtna.prd.freightliner.com/content/dam/public/dtna-servicelit/ddc/pdfs/Lube_Oil_Coolant/Detroit_Bio_Fuel_Position_Statement.pdf)

## **POLICY ON OWNER SERVICE**

### **MAINTENANCE SERVICES**

Proper maintenance and care of the engine will help achieve lower overall operating costs. Use of recommended fuels and lubricants and regular maintenance performed by competent service personnel will help avoid conditions arising from neglect which are not covered by Detroit new product warranties. The maintenance services described in the applicable Operator's Guide should be performed at the time and/or mileage intervals stated, by an Authorized Detroit Service Outlet or any qualified service outlet.

### **PRODUCTION CHANGE**

Detroit reserves the right to make change(s) in design or add improvement(s) on the products at any time without incurring any obligations to install same on products previously purchased. Authorized Service Outlets reserve a similar right.

### **WARRANTY REPAIR ORDER**

For the owner's records, the Authorized Service Outlet will provide a copy of the warranty repair order listing all warranty repairs performed.

## FUEL ADDITIVES

Detroit™ engines are designed to operate satisfactorily on a wide range of diesel fuels. The regular use of aftermarket fuel additives is not required or recommended due to potential fuel injector system or engine damage. Our experience has been that such additives increase operating costs without providing benefit. Aftermarket fuel additive supplements available at most retail stores are intended to be added to the fuel by the customer. These include a variety of independently marketed products which claim to be:

- Cold Flow Improvers (prevents fuel jelling). Lower CFPP (help prevent fuel filter plugging)
- Biocide
- Fuel injection system deposit cleaners or removers
- Oxidative stability
- Cetane Improvers (booster)
- Emission Control Additives
- Fuel Economy
- Smoke Suppressants
- Detergents
- Combustion Improvers
- Icing preventers

Detroit™ recognizes some of the above listed additives may be beneficial in addressing temporary fuel quality issues, but they should not replace proper fuel selection and handling as described in the above sections of the brochure.

Should a customer decide that a supplemental additive is temporarily required; the following is intended to provide guidance to the customer in selecting and additive partner, evaluating potential safety hazards and deleterious engine effects.

- Choose a fuel additive company with strong technical support both in both the field and laboratory. Fuel additive companies should be able to test your fuel and show that it is deficient in some way and be able to demonstrate that their product fixes the finding (s). Companies such as Afton, Infineum, Innospec, and Lubrizol may be considered. Alternately, choose an additive supplier that works closely with these companies.
- Review a Material Safety Data Sheet (MSDS) or a Technical Product Bulletin carefully for special handling instructions and hazardous material content.

- Get a detailed compositional analysis from the supplier. Ash forming metallic elements and corrosive elements must not be present. Additives containing calcium, barium, zinc, phosphorous, sodium, magnesium, iron, copper, and manganese are known to cause combustion ash deposits that can foul fuel injectors and create deposits which may adversely affect cylinder life. Halogenated compounds containing chloride, fluoride, and bromide are corrosive, as are some sulfur containing compounds. Avoid the use of additives with these components. Also, avoid language that says all in one products.
- Be sure to ask your additive supplier to explain the proper handling, mixing, and storage of the additive(s). Be sure to follow all recommendations made by the additive supplier. Improper mixing and storage can negatively affect the performance characteristics of any additive.
- Many additives act as surfactants; evaluate the effect of water separation characteristics on the fuel in combination with the additive. Refer to Table "Diesel Fuel Specifications" for performance requirements.
- Many commercial diesel fuels today contain performance additives, particularly those marketed as premium diesel fuel. Any supplemental additive being considered must be compatible with the fuel it is to be used in. Evaluate a mixture containing twice the recommended concentration of additive for compatibility to represent an over dosage condition, using the tests listed in Table "Diesel Fuel Specifications".
- Conduct performance evaluation of a fuel supplemental additive in customer equipment for a minimum of six months. Testing should be a side-by-side comparison with and without the additive to verify performance claims. Testimonials do not guarantee similar performance in all applications.

The use of supplemental fuel additives does not necessarily void the engine warranty. However, warranty and repair expenses which are determined, by Detroit Diesel or its representative, to have resulted from a fuel additive will not be covered. Accompany these products with performance data supporting their merit as well as the manufacturer's warranty policy.

Detroit™ will not test or verify the performance of any aftermarket additives. It will not accept responsibility for the use, selection, or hazards relating to the use of such products.



## FUEL ADDITIVES THAT ARE NOT ALLOWED

The following fuel additives are NOT allowed:

- Used Lubricating Oil - Detroit™ specifically prohibits the use of drained lubricating oil in diesel fuel. Used lubricating oil contains combustion acids and particulate materials, which erode injector components, resulting in loss of power and increased exhaust emissions. In addition, the use of drained lubricating oil will increase maintenance requirements due to filter plugging and combustion deposits. [Refer to section "Recycled / Re-Refined Oils"](#) for recommendations on proper used oil disposal.
- Gasoline - The addition of gasoline to diesel fuel will create a serious fire hazard. The presence of gasoline in diesel fuel will reduce the fuel cetane number and increase combustion temperatures.
- Ethanol - The addition of ethanol to diesel fuel will create a serious fire hazard. The presence of ethanol in diesel fuel will reduce the fuel cetane number and increase combustion temperatures. Drain and clean tanks that contain such mixtures as soon as possible. Detroit™ will not be responsible for any detrimental effects which it determines resulted from the use of used lubricating oil, gasoline, or ethanol in diesel fuel.

## WARRANTY IMPLICATIONS:

- Detroit Diesel is not responsible for the cost of maintenance or repairs due to the lack of performance of required maintenance services or the failure to use fuel, oil, lubricants, and coolants meeting Detroit Diesel-recommended specifications. Performance of required maintenance and use of proper fuel, oil, lubricants, and coolants are the responsibility of the owner. For full details, see the engine operator's guide for your engine.
- Using biodiesel blends does not automatically void Detroit Diesel's warranty. However, any failure, including aftertreatment devices and fuel injection system failures, determined to be caused by biodiesel blends not meeting the requirements documented in this publication will not be covered by Detroit Diesel warranty.

## **CUSTOMER ASSISTANCE PROCEDURE**

Detroit has established a two-step procedure which customers should follow when experiencing a problem with any Detroit product or Part. Detroit fully realizes that ultimately the customer's concerns will be resolved at the Distributor/Dealer level and therefore encourages customers to follow the procedure outlined below:

### **Step One**

Customers should discuss the problem with member(s) of management from the Authorized Service Outlet. Frequently, complaints are the result of a breakdown in communication and can quickly be resolved by a member of management. If they have already discussed the problem with the Distributor or Dealer's Sales or Service Manager, they should contact the General Manager.

### **Step Two**

If you are still not satisfied, present the entire matter in writing or by phone to:

#### **Warranty Manager**

**Detroit**

**13400 Outer Drive, West**

**Detroit, Michigan 48239-4001**

**Phone: (313) 592-5000**

**Fax: (313) 592-5888**

**Website: [www.demanddetroit.com](http://www.demanddetroit.com)**

## MAINTENANCE RECORD LOG

DATE	KILOMETERS/MILES	SERVICE PERFORMED

## MAINTENANCE RECORD (continued)

DATE	KILOMETERS/MILES	SERVICE PERFORMED