

1 08 07-18



Service Information Bulletin

SUBJECT	DATE
SPN 522222 (CPC3) (GHG17)	August 2018

Additions, Revisions, or Updates

Publication Number / Title	Platform	Section Title	Change
DDC-SVC-MAN-0191	GHG17 DD HD Platform	SPN 522222/FMI 2 - GHG17	These are new sections.
		SPN 522222/FMI 13 - GHG17	

DiagnosticLink users: Please update the troubleshooting guides in DiagnosticLink with this newest version. To update the tool troubleshooting guide, open DiagnosticLink and from the Help – Troubleshooting Guides menu, select the appropriate troubleshooting manual, then click Update.



13400 Outer Drive, West, Detroit, Michigan 48239-4001
Telephone: 313-592-5000
www.demanddetroit.com

2 SPN 522222/FMI 2 - GHG17

CPC Internal - EEPROM Checksum Error

This fault indicates the CPC3evo has detected an internal EEPROM checksum error. This fault generally occurs after a programming event. Using DiagnosticLink[®] 8.08 or higher reprogram the CPC3evo module to latest settings.

3 SPN 522222/FMI 13 - GHG17

CPC Internal - EEPROM Data Verification

Check as follows:

1. This fault indicates the CPC3evo has detected an internal EEPROM Data verification. This fault generally occurs after a programming event. Using DiagnosticLink® 8.08 or higher reprogram the CPC3evo module to latest settings.